

## CLARIS plus filter cartridge – Water for perfect coffee

Use of a CLARIS plus filter cartridge guarantees you freshly filtered, delicious-tasting coffee and hot water at all times. Designed specially for JURA coffee machines, it has a neutral pH value and is placed directly in the water tank.

Unlike other water filtering systems for domestic use, CLARIS plus works according to the professional up-flow principle. In practical terms this means that only the precise amount of water required for a given beverage is drawn in, and this is filtered directly before use.

### No more descaling

If you use the filter cartridge regularly, you will be able to save yourself the time-consuming effort of regular descaling. Your coffee machine will also reward you with a longer service life. Use a CLARIS plus filter cartridge if the water hardness is higher than 10° dH. You can determine the water hardness before using your JURA coffee machine for the first time with the Aquadur® test strip supplied with the machine.

### Easy to operate

Inserting the CLARIS plus filter cartridge could not be easier. A description is contained in Chapter 'Preparing and using for the first time – Using and activating filter'.

### Economical use

After 50 litres of water have been dispensed or after two months at the latest, the filter capacity will be reached. The cartridge must then be replaced. Your JURA coffee machine will prompt you to change the filter. This procedure is described in detail in Chapter 'Maintenance – Changing the filter following a prompt'.

You can return used filter cartridges to the stockist.

### Maintenance and storage

The CLARIS plus filter cartridge only needs to be removed from the water tank if you are away for a prolonged period of time or if you wish to clean or descale the tank using a conventional product.

If you do plan to be away for some time (e.g. on holiday), we recommend that you store the filter cartridge as follows: Remove the cartridge from the water tank. Place it in a glass with about two centimetres of water and put it in the refrigerator.

## CLARIS plus filter cartridge – Water for perfect coffee

We recommend that you prepare about half a litre of water through the machine before starting to make coffee again. The water could be discoloured, but this is not harmful to your health.

### Pictures on the next few pages:

1 Water – always pleasant and freshly filtered.

2 CLARIS plus filter cartridges do not require any accessories and do not take up any extra space. They can be inserted directly into the water tank.

3 4 Water for perfect coffee specialities.

5 The professional up-flow principle: Only the precise amount of water required for a given beverage is drawn in, and this is filtered directly before use.

6 Stainless steel pipes in the heater element: With CLARIS plus (left) you can omit the time-consuming descaling operation (right).

7 The following substances are filtered out through the interaction with organic materials: calcium (Ca), chlorine (Cl), lead (Pb), copper (Cu), aluminium (Al).



1



2



3








5



6



7