



Auto Cappuccino Cleaner

Liquid cleaner for milk systems for cleaning JURA fully automatic machines for coffee specialities

Action

Alkaline cleaner specially developed for JURA fully automatic machines for coffee specialities, for thoroughly removing milk residues and milk fat. The formulation is precisely adapted for use in JURA fully automatic machines for coffee specialities, and ensures extremely effective cleaning without damaging the material. As a result, the service life of your fully automatic machine for coffee specialities is extended. The liquid cleaner can also be used in other areas, e.g. for cleaning manually operated milk foamers.

Properties

Liquid, transparent/milky
Neutral odour
Soluble in water
pH value (20 °C), 12 °dH:
10 ml/100 ml: 11

Constituents

Sodium carbonate
Cationic tensides
Non-ionic tensides

Recommended use

1. Dissolve the quantity of Auto Cappuccino Cleaner recommended in the operating instructions of your machine in the quantity of water recommended for your machine.
2. Start the cleaning operation as described in the operating instructions.
3. At the end of the cleaning operation, rinse the machine with clear water as described in the operating instructions.

Mixing ratio for IMPRESSA X9: 1½ capfuls in 400 ml water.

Mixing ratio for all other JURA machines: 1 capful in 250 ml water.

Toxicological and environmental data

The product is an irritant, i.e. temporary, protracted or repeated contact with the skin can lead to inflammation.

The function of public sewage treatment plants is not affected even when relatively high volumes are added. Biodegradability is in accordance with the applicable conditions of the Washing and Cleaning Agents Act (WRMG – German Law).

Notes on handling, storage and disposal

Close the bottle securely after use.

Product waste code: 20 01 30

All constituents are biodegradable. Residual product can be disposed of down the drain.

Danger notes

Xi – Irritant.

R36/38: Irritating to eyes/irritating to skin.

S02: Keep out of the reach of children.

S26: In case of contact with eyes, rinse immediately with plenty of water and consult a doctor.

S46: If swallowed, seek medical advice immediately and show this container or label.

First-aid measures

Immediately remove contaminated, **wetted clothing**.

If the Cappuccino Cleaner or the prepared cleaning solution is **swallowed**, rinse out the mouth and drink plenty of water. Consult a doctor.

If the Cappuccino Cleaner or the prepared cleaning solution gets onto the **skin**, immediately rinse off with plenty of water.

If the Cappuccino Cleaner or the prepared cleaning solution gets into the **eyes**, immediately rinse with plenty of water. Consult a doctor.

Packing units

Bottles with 100 ml

Bottles with 250 ml

Bottles with 1000 ml

Article numbers

62536, 63801, 66361, 66549