



Cleaning tablets

Tablets for cleaning JURA fully automatic machines for coffee specialities

Action

Alkaline cleaning tablets specially developed for JURA fully automatic machines for coffee specialities, for thoroughly removing coffee fat and coffee residues. The formulation is precisely adapted for use in JURA fully automatic machines for coffee specialities, and ensures extremely effective cleaning without damaging the material. As a result, the service life of your fully automatic machine for coffee specialities is extended. They can also be used for cleaning thermos flasks and other containers/utensils in which there are deposits. Make sure the tablets are dissolved in water at a temperature of at least 90 °C.

Properties

Tablet, convex hemisphere, white
Neutral odour
Height: 11 mm
Diameter: 15 mm
Weight: 2.3 g
Soluble in water
pH value (20 °C), 12 °dH:
2.3 g/l: 9,4
Dissolving time (0.25 l/90 °C): 8 min

Constituents

Anionic tensides
Sodium carbonate peroxihydrate

Recommended use

1. Place a receptacle under the coffee spout.
2. Start the cleaning operation as described in the operating instructions.
3. Pop the tablet into the filler funnel for pre-ground coffee at the time specified in the operating instructions.
4. The rest of the procedure is described in the operating instructions.

Toxicological and environmental data

The product is an irritant, i.e. temporary, protracted or repeated contact with the skin can lead to inflammation.

The function of public sewage treatment plants is not affected even when relatively high volumes are added. Biodegradability is in accordance with the applicable conditions of the Washing and Cleaning Agents Act (WRMG – German Law).

Notes on handling, storage and disposal

Keep the package tightly closed, protect against atmospheric moisture, water and heat.

Product waste code: 20 01 30

All constituents are biodegradable. Residual product can be disposed of down the drain.

Danger notes

Xi – Irritant.

R36: Irritating to eyes.

S02: Keep out of the reach of children.

S26: In case of contact with eyes, rinse immediately with plenty of water and consult a doctor.

S46: If swallowed, seek medical advice immediately and show this container or label.

First-aid measures

If the tablet, abraded material from the tablet or the prepared cleaning solution gets into the **eyes**, immediately rinse with plenty of water.

Consult a doctor.

If the tablet, abraded material from the tablet or the prepared cleaning solution is **swallowed**, rinse out the mouth and drink plenty of water.

Consult a doctor.

If the cleaning solution gets onto the **skin**, immediately rinse off with plenty of water.

Packing units

Folding box with 2 tablets in a blister pack

Folding box with 6 tablets in a blister pack

Tin with 25 tablets

Tin with 100 tablets

Article numbers

58710, 61079, 62535, 62715, 64308, 66163

JURA Elektroapparate AG

Kaffeeweltstraße 10

CH-4626 Niederbuchsiten

Tel. +41 (0) 62 389 81 81

JURA Elektrogeräte Vertriebs-GmbH

Postfach 99 01 44

D-90268 Nürnberg

Tel. +49 (0) 911 25 25-0